

BlackTantra

VIBRATION

STROKER

WEBSITE & OFFLINE SETUP

INTERACTIVE FUNSCRIPT GUIDE

Feel every **beat** of the content.


Connect your vibrator or stroker to BlackTantra's videos and audio — on the website, or on your own computer. A simple guide for funscripts to unlock the next level of immersion.

● INTERACTIVE

Choose your script ▾

SYNCING

SCRIPT — 16,893 actions



SETUP TIME

5 – 10 MIN

YOU NEED

A DEVICE + INTIFACE

WORKS ON

WINDOWS • MACOS

PHONES

NOT YET

FEATURING
LILY

Are you sure you want to give me control of your cock?



Choose your device

Each script is made for one kind of device — a vibrator or a stroker — so you only need one of each. These are the two we build and test the scripts on.

01

FEATURING
LILIANA*Let's play a
game together*

VIBRATION · RECOMMENDED

Gush 2 Motion

#1 FOR HFO CONTENT

- A powerful hands-free glans vibrator.
- Feel the clench and squeeze sensations from your favorite HFO videos.
- Connects to the website in one click through Intiface.

[GET THE GUSH 2 MOTION](#) →[Lovense store](#) · up to **55% off**ALSO WORKS [Diamo](#) [Edge 2](#) [Hush 2](#)

STROKING · RECOMMENDED

The Handy 2

#1 FOR JOI CONTENT

- The best stroking toy on the market.
- Battery powered, USB-C fast charging, with a strong, quieter motor.
- Connects to the website through both Intiface and Handy's Wi-Fi API.

[GET THE HANDY 2](#) →**15% off** through this link — or use the code belowAT CHECKOUT: **BLACKTANTRA**

CHOOSE YOUR PATH

ON THE WEBSITE
Intiface · any toy

[Continue](#)

ON THE WEBSITE
Handy 1 & 2 by Wi-Fi

[Ch 4](#) →

OFFLINE
Your own player


[Ch 5](#) →

Set up Intiface Central

The free app that talks to your device. Install **Intiface Central 3** or newer from intiface.com/central — the website and the local player both connect through it.

● Cush 2 Motion


Pairs over Bluetooth. Switch it on. If you're using the Lovense USB dongle, toggle it on in **App Modes** settings first.



- 1 Start the server — the big button; it reads “Engine running”.
- 2 Devices → Start Scanning, Cush 2 Motion switched on.
- 3 It shows under **Connected Devices**, with its battery.

● The Handy 2

Pairs over Legacy Bluetooth Mode. Switch it on, hold the connect button and the up key at the same time until the light turns teal.



- 1 Start the server — the big button; it reads “Engine running”.
- 2 Devices → Start Scanning, Handy 2 on teal.
- 3 It shows under **Connected Devices** as Linear.

02

FEATURING
ASHLEY

You will
Leak for me



Connect on the website

With Intiface running, go to blacktantra.net and choose a video or audio.
For Adventurer patrons+ the Interactive widget appears on the content page.

03

FEATURING
ASHLYN

We're connected now

- 1 Open the panel**
Click the Interactive panel to open the widget.

1

INTERACTIVE

- 2 Connect Device**
If your browser asks to allow a local connection, allow it.
Your device will appear with its battery.

2

CONNECT DEVICE

- 3 Pick the script**
The type follows your device. Choose a version from the available variations.

INTERACTIVE

Main — Vibration

PAUSED

VIBRATION

STROKING

SCRIPT VERSION

3

Easy

Squeeze

Burst

Gush 2 Motion

82%

Vibration

SCRIPT & SETTINGS

DISCONNECT

CALIBRATE

4

- 4 Calibrate your device**
Click *Calibrate Sync* and play the pattern to set the latency for your device.

- 5 Press play**
Pause or skip to your favourite part — the device stays in sync. You're good to go: enjoy the experience.

Customising or troubleshooting? [Skip to Chapter 7](#) →



The Handy by Wi-Fi

For the Handy 1 and 2: connect straight from the website with your connection key over Wi-Fi — no Intiface, no Bluetooth.

04

FEATURING
DAKINI*You'll learn to worship*

1 Put your Handy on Wi-Fi

Switch it on and connect to your Wi-Fi in the Handy Onboarding app. The light turns **magenta** once it's online.



2 Copy your connection key

You can find it in the Handy Onboarding app. [How to find it](#)

Your Connection key What is this? ?

ABCDEFGH12345

Copy

3 Open the widget

At the bottom, click **Connect it by Wi-Fi instead**.

CONNECT DEVICE

SETUP GUIDE

Have a Handy? **Connect it by Wi-Fi instead**

4 Paste the key, press Connect

It's remembered in your browser, so next time it connects on its own.

CONNECT DEVICE

THE HANDY · WI-FI

Cancel

ABCDEFGH12345

CONNECT

5 Press play

Press play and give in — every stroke now follows the scene. Pause or skip whenever you like; the Handy keeps up.

SYNCED



Why Wi-Fi? The Handy plays the script from its own memory, timed to Handy's servers — the smoothest playback with nothing to install.



Set up a local player

Download the files and play the funscripts over your own Bluetooth connection. You need **Intiface** and an app like **MultiFunPlayer**, which links your device to your preferred video player.

1 Install the software

Download [MultiFunPlayer](#) and a compatible video player — the project recommends [PotPlayer](#).

2 Add your video player

Press the + in the top-right corner and select your video player (PotPlayer) from the dropdown. It will display *Connected* in green.

3 Add Buttplug

Scroll to the bottom, press the + and add [Buttplug.io](#) from the dropdown.

4 Connect Intiface


Press ► to connect to Intiface. It will display *Connected* in green.

5 Connect your device

Open the small ▼ beside Device map. Axis V0 for vibration or L0 for stroking, pick your device, then +. The row turns green.

Vibration, once only: ⚙ Settings in the top bar → **Device** tab → **TCode-0.3** → tick **V0**, then restart MultiFunPlayer.

[MultiFunPlayer wiki](#) — every option explained ↗



CHOOSE YOUR VIDEO PLAYER

PotPlayer **RECOMMENDED**

VLC

MPC-HC

MPV

VR

DeoVR

HereSphere

05

FEATURING
SOPHIA

Awe, is it too hard?



Play a file

Watch or listen with your own video player: download the file and its funscript, then load them into MultiFunPlayer to sync your device.

06

FEATURING
JERRICA*Lilith sent me to help*

1

Download the file & funscript

Download the files from the access folder in your [account dashboard](#).

Use the search in the Funscript Library to find your script.

[Open the Funscript Library](#) →

2

Open the file in PotPlayer

Press play. Its name will appear in MultiFunPlayer's *File* box.

3

Load the funscript

Open your device's tab — V0 vibration, L0 stroking — then click the file icon, click **Load** and choose your funscript file.

4


Set the Offset

Start at 0.00 s. It works like the website's Latency: **-40 ms** there is **-0.04 s** here — negative makes the device act earlier. Scale sets the strength — see Chapter 7.

5

Press play

Start the video and enjoy — the heat map lights up when everything's linked.



ADEPT VR videos

- 1 Install **DeoVR** (free) on your Quest VR headset.
- 2 Connect to your PC and transfer the video to the headset.
- 3 Developer settings in DeoVR → turn on **Remote control**.
- 4 Click Wi-Fi in the Quest settings to find your IP address.
- 5 On the PC, connect your device in Intiface + MultiFunPlayer.
- 6 Add **DeoVR** to MultiFunPlayer → enter your IP followed by 23554 (Ex: 192.168.1.100:23554).
- 7 Load the funscript and press play in DeoVR.




Make it yours

Two settings make it yours: **Latency** for timing and **Strength** for intensity. Both live under Script & settings in the widget, and are remembered per device.

Latency TIMING

Press **Calibrate** in the widget and a small window appears. Start the pattern, then move Latency until each stroke or buzz lands as it reaches the line, and press **Done**.

● SYNC CALIBRATION



SIM STROKER Playing on your device.

STOP

LATENCY - + 0 ms

Change it two ways: in the **calibration tool**, or **live** while you watch — Script & settings in the widget. + makes the device act later, - earlier. Most setups sit between **-40 and +40 ms**.

- / +
10 ms a press

Click the value
to type one

Double-click
resets to 0

Strength & stroke range INTENSITY

One slider, named for your device.

Vibrator · Strength — how strong the vibration is.

STRENGTH 60%

Stroker · Stroke range — how long each stroke is.

STROKE RANGE 60%

Difficulty WHERE TO START

VIBRATION · STRENGTH

5-15%
BEGINNER

30-50%
MEDIUM

60-80%
HARD

100%
EXTREME

Playing locally? MultiFunPlayer's Scale goes up to 400%, but your device tops out at 100% — above that it only lifts the quieter parts.

HANDY · STROKE RANGE

50-70%
WARM-UP

100%
FULL

Below 50% the strokes start to feel a bit short. Experiment to find what you enjoy most with your device.

Fall deeper for Princess

FEATURING
ALYSSA



If something's off

Almost everything comes down to one of these.

08

FEATURING
YUNO

WEBSITE · INTIFACE

“Couldn’t reach Intiface”

Press the big button so it reads **Engine running**, and make sure to allow the browser’s local connection: the icon left of the website URL → Enable **Local network access**.

Connected, no device listed

Intiface → Devices → **Start Scanning**, with the device switched on and charged.

Handy 2 not found

It needs **Legacy Bluetooth Mode**: hold the connect button and the up key together until the light turns teal, then scan again.

WEBSITE · HANDY WI-FI

“Your Handy is offline”

The light must be **magenta** (on Wi-Fi) — blue is Bluetooth mode. The Handy only joins **2.4 GHz** Wi-Fi, so make sure your router broadcasts it.

It keeps dropping off Wi-Fi

Move it closer to the router, or connect it to your **phone’s hotspot** instead.

“Key not accepted”

Copy it again from the Handy Onboarding app and paste the whole key.

“Script didn’t reach your Handy”

Press **Try again** — the Handy downloads it over your internet.

OFFLINE · LOCAL PLAYER

No device in MultiFunPlayer

Start Intiface’s engine, then press ► on the Buttplug.io card.

PotPlayer isn’t Connected

Open the video in PotPlayer first; MultiFunPlayer finds it.

The heat map stays empty

Load the script on your device’s tab (file icon → **Load**). For automatic loading it must sit in the video’s folder with the same name: **video.funscript** (L0) or **video.vib.funscript** (V0).

Don't give up so soon..

ON ANY CONNECTION

The beat lands late or early

Adjust **Latency** (website) or **Offset** (local) in small steps.

“In use in another tab”

One page drives the device at a time: **Use here**, or close the other tab.

No Interactive panel

No script yet, or it’s on the Extended version — the strip under the player says which.

On your phone

Not yet — the Interactive widget is desktop only for now.

RESOURCES

[Intiface Central](#)

[MultiFunPlayer](#)

[PotPlayer](#)

[Funscript Library](#)

[Gush 2 Motion guide](#)

[Handy Help Center](#)

[Handy · connection key](#)

[Handy · light colours](#)

[Handy · connection issues](#)



BlackTantra

SETUP COMPLETE

Your test begins.

"That wasn't too hard, right? Let's see how long you'll last now that you've given me complete control over your cock. You're mine now."

— LILITH

Pick a video or an audio, press play, and prepare for the pleasure.

30+


video funscripts

19+

audio funscripts

New

releases every month



Gush 2 Motion

Hands-free vibration · for HFO lovers

GET THE GUSH 2 MOTION

Best deal



The Handy 2

Precise stroking · for immersive JOIs

GET THE HANDY 2

15% off

[Browse videos](#) [Browse audio](#) [Download files](#) [Funscript Library](#)

blacktantra.net · Affiliate links support the project at no cost to you

FEATURING
MELODY

What are you waiting for?

